



# How to reset default settings on MiniMag II or SecureMag

 This works with all the IDTECH USB/HID, USBKB & RS232 interface card readers that this Configuration software supports. (e.g. SecureMag, Easy Mag, SecureHead, etc.)

1. Launch the [MagSwipe Configuration Software](#) with the reader connected through USB



- 2.