


How to control which tracks are output on SecureMag, SecureHead, MiniMag, Omni?

You can use the MagSwipe Configuration Utility to turn off/on any combination of the 3 tracks on a 3 track reader.



Related Links:

[MagSwipe Configuration Utility - Home](#)